



“The lid on my Brabantia NewIcon Pedal bin does not close”



This issue is likely due to one of these two reasons:

1. The bin may have been pushed out of alignment.

See here how to re-shape your bin:

https://www.youtube.com/watch?v=gDZy1smLdQU&list=PLz-9_6gOcr_p8yIRaR-6lyBfNH3BD5c86&index=32

2. The bin rim may have become loose.

See here how to re-fit the rim:

https://www.youtube.com/watch?v=JCDcx7rlc2k&list=PLz-9_6gOcr_p8yIRaR-6lyBfNH3BD5c86&index=25

If you are still having problems after trouble shooting 1. & 2. above, please contact our Warranty Team by email warranty@sheldonandhammond.com.au or phone 1800 252 624