



**“The lid on my Brabantia NewIcon Pedal Bin has a squeaky sound”**



**There is a very easy fix to a squeaky lid on your Brabantia NewIcon bin; you just need to grease the hinge with Petroleum Jelly.**

**Here is a video showing you how: <https://youtu.be/tlV8yyd-tqI>**