




“The rim and/or hinge on my Brabantia Newlcon Pedal Bin has come off”

**REMOUNT
THE HINGES,
LID AND
UPPER RIM.**



In some instances, the rim and hinge may come off the bin.

Here is a video showing you how to put it back together again:

https://www.youtube.com/watch?v=olTaYuJr_Bc&list=PLz-9_6gOcr_p8yIRaR-6lyBfNH3BD5c86&index=25