



**"My Brabantia BO bin has a squeaky lid"**

**GREASE  
THE HINGE.**



**GREASE  
THE HINGE.**



**To stop the lid on your BO bin from squeaking, you just need to grease the hinge with Petroleum Jelly.**

**Here are some videos showing you how:**

**Brabantia BO Pedal Bin:**

[https://www.youtube.com/watch?v=x0FBYIzUEoU&list=PLz-9\\_6gOcR\\_p8yIRaR-6lyBfNH3BD5c86&index=18](https://www.youtube.com/watch?v=x0FBYIzUEoU&list=PLz-9_6gOcR_p8yIRaR-6lyBfNH3BD5c86&index=18)

**Brabantia BO Touch Bin:**

[https://youtu.be/BP\\_8cHV3I4Q?si=Y52Y99Lsm-gEXmoE](https://youtu.be/BP_8cHV3I4Q?si=Y52Y99Lsm-gEXmoE)